

KIT-F7100


Panic Bar

防火推杠锁系列



KIT-F7100

Panic Bar



Features

1. Alarm kit contains an internal horn and LED light, when the push bar is depressed, the LED light will blink and horn will siren to provide a visible/audible means of signaling that the opening has been violated.
2. The alarm kit can be armed or disarmed by key.
3. Alarm siren time may be adjust to 1,3,5 and infinite minutes.
4. The key switch uses a standard 1-1/4" cylinder with S keyway.
5. Device includes "EMERGENCY EXIT ONLY. ALARM WILL SOUND" decal for application on door or push bar.

Note

1. If alarm siren time is set to infinite minutes, alarm will sound until battery runs out.
2. Siren will beep and red LED will blink at approximately 6 second intervals when battery is low.

Operating Instructions

1. Insert the key into the cylinder and turn counterclockwise to arm the unit.
2. The siren will sound three short beeps indicating the unit is armed.
3. Depress the push bar, the alarm should sound immediately and red/green LED light will blink.
4. Turn the key clockwise to disarm.

arctek



arctek®

architects' choice

www.arctek.com.cn

 WeChat ID : ArctekChina



[上海]

上海市普陀区云岭东路651号合星大厦905室

电话: +86(0)21-6221 6991

传真: +86(0)21-6221 6992

[北京]

北京市朝阳区西大望路3号蓝堡国际中心1座1005室

电话: +86(0)10-8599 7277

传真: +86(0)10-8599 7015